

# REMOTE CONTROL FUNCTION

## TV POSITION BUTTON

Press and hold 3 secs to memorize TV position, press TV button to recall positions.

## ZG POSITION BUTTON

Press and hold 3 secs to memorize ZG position, press ZG button to recall positions.

## HEAD UP/DOWN BUTTON

Press and hold to raise or lower the HEAD section

## TILT UP/DOWN BUTTON

Press and hold to raise or Lower the TILT position

## HEAD INTENSITY PLUS/MINUS BUTTON

Press to increase/decrease intensity

## HEAD & FOOT MESSAGE OFF BUTTON

## FLAT BUTTON

Press and release to lower the bed to FLAT position

## HEAD & FOOT UP BUTTON

Press and hold to raise the HEAD & FOOT section

## FOOT UP/DOWN BUTTON

Press and hold to raise or lower the FOOT section

## HEAD & FOOT DOWN BUTTON

Press and hold to lower the HEAD & FOOT section

## FLASHLIGHT BUTTON

Press to turn on light, Press again to turn off light

## FOOT INTENSITY PLUS/MINUS BUTTON

Press to increase/decrease intensity

## UNDERBED LIGHT BUTTON

Press to turn on/off



How to activate Bluetooth

1. Press and hold HEAD UP & FOOT UP, then press RESET button on dual actuator control box
2. Press and hold HEAD UP & FOOT UP, then press RESET button on bluetooth receiver

Scan below for APP

I.O.S.



Android

